

SYSTEM	ENGINE	CHASSIS	Controller ID	Live Data	Fault Codes	Activation	Clear Adaption	EWS Synch
<b>ENGINE (GAS)</b>								
DME 1.1	M20, M30	E24, E28,E32	YES	YES	YES	YES	NO	NO
DME 1.2	S38, M70	E31, E32, M5	YES	YES	YES	YES	NO	NO
DME 1.3	M20, M30, M40	E30, E32, E34	YES	YES	YES	YES	NO	NO
DME 1.7	M40, M42, M70, S70	E31, E32, E36	YES	YES	YES	YES	NO	NO
DME 1.7.1	M70, S70	E31, E32	YES	YES	YES	YES	NO	NO
DME 1.7.2	M43	E36	YES	YES	YES	YES	NO	NO
DME 3.1	M50	E34, E36	YES	YES	YES	YES	NO	NO
DME 3.3	S38, S50, M60, M60/1	E31, E32, E34, E38, M3, M5	YES	YES	YES	YES	NO	YES
DME 3.3.1	M50 (VANOS)	E34, E36	YES	YES	YES	YES	NO	YES
DME 5.2	M44, M62, M73	E36, E38, E39	YES	YES	YES	YES	NO	YES
DME 5.2.1	M73	E31, E38	YES	YES	YES	NO	YES	YES
MS 40.0	M50 (VANOS)	E34, E36	YES	YES	YES	NO	NO	NO
MS 40.1	M50 (VANOS)	E34, E36	YES	YES	YES	NO	NO	NO
MS 41.0	M52	E36, E38, E39	YES	YES	YES	YES	YES	YES
MS 41.1	M52	E36, E38, E39	YES	YES	YES	YES	YES	YES
MS 41.2	S52	M3	YES	YES	YES	YES	NO	NO
MS S50	S50	M3	YES	YES	YES	YES	YES	YES
MS 42	M52TU	E38, E39, E46	YES	YES	YES	YES	YES	YES
MS43	M54	E38, E46, E53	NO	NO	NO	NO	NO	NO
MS45	M56	E38, E46, E53, E85	NO	NO	NO	NO	NO	NO
MS 46	M43	E46	YES	YES	YES	YES	YES	YES
ME 7.2	M62TU	E38, E39	YES	NO	YES	NO	YES	YES
ME 9.2	N62	E65	NO	NO	NO	NO	NO	NO
ME 9.2.1	N73	E66	NO	NO	NO	NO	NO	NO
<b>ENGINE (DIESEL)</b>								
DDE 2.1	M21	E34, E36	YES	NO	YES	YES	NO	NO
DDE 2.2	M51	E38, E39, E46	YES	NO	YES	YES	NO	NO
DDE 3.0	M41	E36, E46	NO	NO	NO	NO	NO	NO
DDE 4.0	M51	E39, E46	NO	NO	NO	NO	NO	NO

<b>SYSTEM</b>	<b>ENGINE</b>	
<b>ELECTRONIC DRIVE AUTHORIZATION</b>		
<b>EWS II</b>	DME 3.3, 3.3.1, 5.2, 5.2.1, MS41, MS41.1, MSS50	<b>Synchronize Engine Controller to EWS</b>
<b>EWS III, III (3.2), III (3.3), III (3.3D)</b>	MS42, MS43, MS46	<b>Synchronize Engine Controller to EWS</b>

<b>SYSTEM</b>	<b>ENGINE</b>	<b>CHASSIS</b>	<b>Controller ID</b>	<b>Live Data</b>	<b>Fault Codes</b>
<b>THROTTLE CONTROL</b>					
<b>EML M70</b>	M70B50	E32	YES	YES	YES
<b>EML S70</b>	S70B50	E31, E32	YES	YES	YES
<b>EML M30</b>	M30B35	E32, E34	YES	YES	YES
<b>EML IIS M73</b>	M73B54	E31, E38	YES	YES	YES

<b>SYSTEM</b>	<b>TRANSMISSION</b>	<b>CHASSIS</b>	<b>Controller ID</b>	<b>Live Data</b>	<b>Fault Codes</b>	<b>Activation</b>	<b>Clear Adaption</b>
<b>TRANSMISSION</b>							
<b>EGS 1.2YES</b>	4HP-22/24	E32, E34	YES	YES	YES	YES	NO
<b>EGS 2.2YES</b>	4HP-24	E31, E32	YES	YES	YES	YES	NO
<b>EGS 4.1YES</b>	A4S 270R/310R	E34, E36	YES	YES	YES	YES	NO
<b>EGS 7.1YES</b>	A5S 310Z	E34, E36	YES	YES	YES	YES	YES
<b>EGS 7.32</b>	A5S 310Z	E32, E34, E38	YES	YES	YES	YES	YES
<b>AGS 8.32</b>	A5S 310Z	E36, E38, E39	YES	YES	YES	YES	YES
<b>EGS 8.34</b>	A4S 270R/310R	E36, E38, E39	YES	YES	YES	YES	YES
<b>EGS 8.36</b>	A5S 310Z	E36, E38, E39	YES	YES	YES	YES	YES
<b>AGS 8.51</b>	A5S 440Z	E38, E39	YES	YES	YES	YES	YES
<b>AGS 8.55</b>	A5S 440Z	E38, E39	YES	YES	YES	YES	NO
<b>GS 8.60</b>	A5S 360R	E38, E39, E46	YES	YES	YES	NO	NO
<b>EGS 8.70</b>		E36, E38, E39	YES	YES	YES	YES	YES
<b>EGS 9.</b>	A5S 560Z	E34, E38	YES	YES	YES	YES	YES
<b>AGS 9.22</b>	A5S 560Z	E38, E39	YES	YES	YES	YES	YES
<b>GS 20</b>	A5S 360Z (5L60)	E39, E46	YES	YES	YES	NO	NO
<b>Sequential M Gearbox</b>	S38, M52, MSS50	M3, M5	YES	YES	YES	NO	NO
<b>Jatco</b>	M50	E34, E38	YES	YES	YES	NO	NO

SYSTEM	MFG.	CHASSIS	YEARS	Controller ID	Live Data	Fault Codes
<b>TRACTION &amp; BRAKES</b>						
ABS $\mu$ C	Bosch			YES	YES	YES
ASC + T	Bosch	E32 - M70 E31 - M70	1991 1991	YES	YES	YES
ASC+T w/ADS II		E32 - M60 E31 - M60 E34 - M60	1993 1993 1993	YES	YES	YES
ABS MK4.3	Teves	E36 - 325i	9/91-8/93	YES	YES	YES
ABS MK4 G	Teves	E36 - 325i	9/93-	YES	YES	YES
ABS MK4 G1	Teves	E36 - 325i E36 - 318i, 328i, Z3	9/94 1996-	YES	YES	YES
ABS 5	Bosch	E32, E34	1995-96	YES	YES	YES
ABS/DSC 2	Bosch	E38, E31	1995-	YES	YES	YES
ABS/DSC 3	Bosch	E38 - 750iL	7/97	YES	YES	YES
ABS/DSC 5	Bosch			YES	YES	YES
ABS/ASC-EZA	Bosch	Z3, 318		YES	YES	Read Codes Only
ABS/ASC 5	Bosch	E34 - 525i E31 - M60/M62 E38 - M60/M62 E31 - M52/M62 E46 - M52	1994- 1994- 1995- 1995 - to 5/99	YES	YES	YES
ABS/ASC ITT Auto ERL	Teves			YES	YES	YES
ABS MK20-I/ERL	Teves	Z3 - M44 E36 - 318i	3/96-1997 3/96-1997	YES	YES	Read Codes Only
DSC III MK20 EI	Teves	E46	6/99-9/00	YES	YES	YES
DSC III MK60	Teves	E46	10/00-	NO	NO	NO
DSC III 5.7	Bosch	E46/16 - 330i 328i	6/00- 9/00-	NO	NO	NO
ASC 5.7	Bosch	E8 (740, 750) E39 (540)	1999- 1999-	YES	YES	YES

SYSTEM	CHASSIS	YEARS	Controller ID	Fault Codes
<b>SRS/AIRBAG</b>				
5WK4 027	E30, E31, E32, E34	1988-1991	YES	YES
5WK4 060	E31, E32, E34, E36	1991-1993	YES	YES
ZAE, BAE	E31, E32, E34, E36	1993-1995	YES	YES
ZAE2, MRS, MRS2	E31, E36, E38, E39, Z3	1995-1999	YES	YES
MRS3	E38, E39, E46, Z3, E53	1999-2000	YES	YES
MRS4	E38, E39, E46, E53, E85	2001-	NO	NO

SYSTEM	CHASSIS	YEARS	Controller ID	Live Data	Fault Codes
<b>AIR CONDITIONING</b>					
IHK / IHKR / IHKA	E31, E32, E34, E36, E38, E39, E46, E53	1988-2000	YES	YES	YES

SYSTEM	CHASSIS	YEARS	Controller ID	Fault Codes
<b>INSTRUMENT CLUSTER</b>				
COMBI / KOMBI	E36, E38, E39, E46	1990-2000	YES	YES

SYSTEM	CHASSIS	YEARS	iScan VER 4.0
<b>SERVICE INTERVAL (SII for 20 Pin Diagnostic Models Only)</b>			
3 Series	E30 E36, Z3 E46 E46	1988 to end of production 1990 to end of production 7/98 - 8/99 9/99	Reset Oil and Inspection,
5 Series	E34 E39 E53	1988-1995 1996-8/00 1999-8/00	Reset Oil and Inspection,
7 Series	E32 E38	1988-1994 1995-2001	Reset Oil and Inspection,
8 Series	E31	1991-1999	Reset Oil and Inspection,
All	E46 E38 E39 E53	9/99- 9/00- 9/00- 9/00-	Oil and Inspection is performed manually by Trip Reset button

**We currently do not function on any system in the 745 (E65), 760(E66) or Z4 (E85).**